



Security World, Inc.

10 Cedar Street Valhalla, NY 10595

914-761-9500

ALARM SYSTEM INSTRUCTIONS

At main screen push **SECURITY**

To Arm: Make sure keypad indicates ***READY TO ARM***

A. When leaving the house (includes windows, doors and motions)

1. Touch AWAY button, you will hear a beep and will show ARMED, you now have 60 seconds to exit.

B. When Staying on premises (includes windows and doors)

1. Press STAY button, you will hear a beep and will show ARMED, you now have 60 seconds to exit premises (if you choose). It will also give you 30 seconds when re-entering thru a delayed door to disarm system.

C. To Bypass an Open Zone

1. To bypass ALL faulted zones. Touch DISPLAY FAULTS all faulted zones will show on keypad. Touch BYPASS ALL and then arm as usual.

2. To bypass INDIVIDUAL faulted zones. Touch DISPLAY FAULTS and highlight (touch) zone to bypass and touch BYPASS SELECTED and arm as usual

To Disarm:

A. From STAY mode At main screen touch MORE CHOICES>CONSOLE> enter your code

B. Upon entering Enter your user code

Resetting Alarm after Activation

A. Enter your user code two times to clear the alarms